

BLOCK CARNIVAL

D I P S W 1

Item	Condition	1	2	3	4	5	6	7	8
DON'T TOUCH									
Direction	Normal			OFF					
	Reverse			ON					
Demo sound	Yes				OFF				
	No				ON				
DON'T TOUCH	Game					OFF			
	Test					ON			
Coin 1	1 COIN 1 PLAY						OFF	OFF	
	1 COIN 2 PLAY						ON		
	2 COIN 1 PLAY						OFF	ON	
	2 COIN 3 PLAY						ON		
Coin 2	1 COIN 1 PLAY							OFF	OFF
	1 COIN 2 PLAY							ON	
	2 COIN 1 PLAY							OFF	
	2 COIN 3 PLAY							ON	

D I P S W 2

Item	Condition	1	2	3	4	5	6	7	8
Difficulty	Normal	OFF							
	Easy	ON	OFF						
	Hard	OFF							
	Very Hard	ON	ON						
Ball extend	20,000/Each 50,000			OFF	OFF				
	30,000/Each 60,000			ON					
	20,000/Each 70,000			OFF	ON				
	30,000/Each 90,000			ON					
Player Stock	2					OFF	OFF		
	3					ON			
	4					OFF	ON		
	1					ON			
DON'T TOUCH								OFF	
								ON	
DON'T TOUCH									OFF
									ON